Notes	
A	Narrow bore connection under the inlet manifold. Inlet manifolds vary. There may be more than one of these connections under the manifold. If so the rear most one should be blanked off to avoid contact with e steering column and the alternative connection should be used.
В	Narrow bore connection on top of inlet manifold
С	Wide bore connection under the inlet manifold
D	Wide bore connection on top of the inlet manifold

